

31 3/4" Entry Door
Rails
(27.625)

31 3/4" Entry Door
Stiles
(79.5)

36" Entry Door
Rails
(31.875)

36" Entry Door
Stiles
(79.875)

Main Screen

Page 1

Page 2

Page 3

Page 4

Offset = None

Select a Button to Set

Unload

RazorGage Entry Screen

Please enter a label for the button (may be left blank)

Creating a new button is simple

Please enter the actual Position for the button.

123.456

7	8	9	CANCEL
4	5	6	ENTER/OK
1	2	3	
.	0	BackSpace	